





**KELMAR**

Systems Inc., 284 Broadway, Huntington Station, NY 11746 • 631.421.1230 • FAX 631.421.1274

## Christie AMK Automation Terminations

TB-1

1	GROUND
2	120VAC NEUTRAL FEED
3	120VAC LINE FEED
4	CHANGEOVER FEED
5	CHANGEOVER OPEN
6	CHANGEOVER CLOSE
7	MOTOR IN
8	MOTOR OUT
9	LAMP IN
10	LAMP OUT
11	FEED TO FAILSAFE
12	RETURN FROM FAILSAFE
13	ALARM
14	FORMAT CUE
15	SHOW END CUE
16	LENS 
17	LENS 
18	GROUND
19	GROUND
20	AUX. FEED
21	AUX. PULSE
22	AUX. PULSE
23	
24	
25	



**KELMAR**

Systems Inc., 284 Broadway, Huntington Station, NY 11746 • 631.421.1230 • FAX 631.421.1274

## **Christie AMK Automation Terminations**

TB-2

26

27

EXCITER IN

28

EXCITER OUT

29

ALARM

30

31

REMOTE START

32

GROUND

33

CURTAIN OPEN (LIGHT CURTAIN OFF)

34

LIGHT CURTAIN ON

35

CURTAIN FEED

36

CURTAIN CLOSE

37

DIMMER RAISE

38

DIMMER DOWN

39

DIMMER FEED

40

MUSIC OFF

41

MUSIC ON

42

MUSIC FEED IN

43

MASKING FEED

44

MASKING

45

MASKING

46

K8 SPARE RELAY COIL

47

K8 SPARE RELAY COIL

48

K8 SPARE RELAY FEED

49

K8 SPARE RELAY N.C. CONTACT

50

K8 SPARE RELAY N.O. CONTACT