

ATD- 1274 Century Dolby Digital/Analog Basement Reader

INSTALLATION NOTES FOR KELMAR ATD -1274

LED ASSEMBLY:

LED Cables are tagged for reference of ANALOG, DIGITAL and POLARITY.

READER ASSEMBLY:

Remove the lower Analog Reader from the Main Assembly before installing in the SOUNDHEAD.

DO NOT INSTALL THE ANALOG READER UNTIL THE DIGITAL PORTION HAS BEEN ALIGNED. If for any reason you can not get Digital to perform then install the Analog Reader temporarily.

The Digital Reader has been preset at the factory for the proper alignment of the lens tube to the lateral guide roller.

DO NOT ADJUST THE LATERAL GUIDE ROLLER ALL LATERAL ADJUSTMENTS MUST BE MADE AT THE BACK OF THE READERS.

To align LED to Pickup tube, turn the system on and move the LED Arm up and down until you get the Maximum video output from the processor, then tighten down the LED Arm screws.

Now the Analog Reader may be installed. For a rough alignment secure the Reader to the Main base but only tighten the mounting screws finger tight. Thread up Cat69-T Dolby Tone test film and move the Reader Assembly up and down until You get the most output from the Reader. Then follow Instructions enclosed for the AT-1200.